

Mechanical Slot Machine - Model -			
Item:	Problem:	Remedy:	Reason:
Casing			
Key			
Lock			
Bonnet			
Friction Locks			
Bolt Holding Mechanism to Casing			
Mechanism			
Coin Entry			
Slug Container			
Sensing Pin			
Magnet Cover			
Coin Detector Lever Assembly (Horizontal)			
Check Detector Lever (Horizontal)			
Coin Detector Operating Lever (Vertical)			
Check Detector Operating Arm Assembly (Vertical)			

Mechanical Slot Machine - Model -			
Item:	Problem:	Remedy:	Reason:
Vertical Payout Pushback Lever			
Springs			
Escalator Chain (if present)			
Cotter Pins On Springs			
Escalator			
Coin Sensing Prongs			
Coin Advance Bar Lever Assembly			
Coin Advance Bar Locking Lever			
Payout Tube			
Jackpot Assembly			
Overflow Container			
Clock Fan			
Clock Fan Fins			
Clock Spring			
Fan Gear			
Idler Gear			
Main Operating Fork			

Mechanical Slot Machine - Model -			
Item:	Problem:	Remedy:	Reason:
Pump Assembly			
Screws (Wood)			
Cotter Pins			
Washers			
Lock Washers			
Glass Windows			
Exterior Finish			
Serial Numbers			
Part Numbers			
Money Bowl			
Reward Plate			
Handle			
Handle Bushing			
Handle Spring			
Stud Rollers			
Screws (Metal)			
Coin Tube Loading Arm			
Coin Advance Bar Operating Lever			
Coin Advance Bar Operating Lever Spring			
Main Operating Lever Spring			
Other			

Mechanical Slot Machine - Model -			
Item:	Problem:	Remedy:	Reason:
Safety Slide Lever Assembly (Bottom)			
Safety Slide (Bottom)			
Extension Spring (1)			
Bottom Payout Slide			
Extension Spring (2)			
Intermediate Payout Slide			
Extension Spring (3)			
Heavy Payout Slide Assembly			
Extension Spring (4)			
Top Payout Slide Assembly			
Extension Spring (5)			
Payout Slide Cover Assembly			
Other			
Other			
Other			

Mechanical Slot Machine - Model -
Additional Information:
1.
2.
3.
4.
5.
6.
7.
8.
9.
10.

There are several stages of operation for your mechanical machine.

1. Coining
2. Wind-up Cycle
3. Release
4. Unwind Cycle
5. Indexing
6. Payout

Listen for five (5) clicks or noises EVENLY SPACED time-wise:

1. Reel Number 1 (left reel) comes to a stop.
2. Reel Number 2 (center reel) comes to a stop.
3. Reel Number 3 (right reel) comes to a stop.
4. Vertical payout pushback lever releases the vertical payout levers.
5. Payout slides reset.

If any one of these audible motions DOES NOT occur, the machine is jammed. A coin (especially a small, thin coin like a dime) can be wedged in: the clock fan, escalator, payout slides, payout tube, other levers, other coins.

If you decide to remove the jam, follow these directions:

- a. Open the back of the slot machine.
- b. Remove the bonnet.
- c. Lift the friction tabs and undo the bolt (if a bolt is present) holding the mechanism to the casing.
- d. Slide the mechanism out of the casing and place it on an old towel (to absorb grease, oils, etc.)
- e. Examine each section where the jam may have occurred (as we showed you during our repair visit to you.)

Payout Verifications - Model -				
Reel Symbols: Left, Center, Right 1 2 3	Reels Spin and Index?		Number of Coins (On Payout Table)	Actual Number of Coins Received
Cherry	Y	N		
Cherry, Cherry	Y	N		
Cherry, Cherry, Cherry	Y	N		
Melon, Melon, Melon	Y	N		
Orange, Orange, Orange	Y	N		
Plum, Plum, Plum	Y	N		
Bell, Bell, Bell	Y	N		
7, 7, 7	Y	N		
Bar, Bar, Bar	Y	N		
Other Symbols				
	Y	N		
Other Symbols				
	Y	N		
Other Symbols				
	Y	N		
Other Symbols				
	Y	N		
Other Symbols				
	Y	N		

Mechanical Slot Machine - Model -
Recommendations
1. If power is required to operate the lights/bell, keep the machine UN plugged until it is ready to be used. (Plug-in models only.)
2. Plug the machine into a grounded 3-prong outlet. (Plug-in models only.)
3. Play ONLY one coin. Play the correct denomination coin. Do NOT add additional coins. Mechanical slot machines rarely play more than one coin.
4. Wait for the coin to drop through the coin entrance to rest against the sensing pin.
5. Pull the handle down completely. Let it return under its own force.
6. The machine should start its windup mode.
7. During the unwind mode all three reels should audibly/visually index.
8. Wait for any payout of coins. Do not shake or hit the slot machine.
9. DO NOT force the machine's handle if it jams.
10. DO NOT use any "water displacement" type sprays in or on your slot machine.
11. Use petroleum jelly on the main operating fork instead of grease.
12. Use a light sewing machine oil on any metal/metal surfaces.
13. DO NOT lubricate the slides with any lubricant (liquid, powder, oils, etc.)
14. DO NOT adjust springs, screws, bolts, nuts, gears or levers.
15. DO NOT attempt to adjust the odds or payouts. These are fixed.
16. DO NOT lose the key to the front jackpot panel (if there is one).
17. DO NOT lose your temper.
18. DO NOT open the machine to "tinker" with it. There is nothing to adjust.
19. DO NOT lose the rear cabinet keys. Some types of keys are nearly impossible to reproduce. Some of the locks are very difficult to enter and pick open. (I know, I have tried. - Thomas Baker)
20. Be gentle with your mechanical slot machine. It is many decades old.
Other:
Other:
Other:
Other: